この度は弊社製品をお買い上げいただき、 誠にありがとうございました。 ご使用の前にこの説明書をよくお読みの上 正しくご愛用くださいますよう、お願い申 し上げます。 なお、この説明書はお手元に保管し、必要 に応じてご覧ください。

弊社製品についての修理その他のご相談は、「お買い上げ店」で うけたまわっております。なお、ご不明の点は下記へお問い合せ 取扱説明書 全国共通フリーダイヤル 0120-612-911

> お客様相談室 〒100-0005東京都千代田区丸の内 3-1-1 国際ビル 〒550-0013大阪市西区新町 1-4-24 大阪四9橋新町ビルディング セイコーウオッチ株式会社

> > Button (

セイコーウオッチ株式会社

本 社 〒105-8467 東京都港区芝浦1-2-1 http://www.seiko-watch.co.jp/

Tapping × one time: Turning on the built-in light Tapping × two times: Setting/canceling the auto illumination Press Button (1) to change the display to the TIME/CALENDAR display.

BUTTONS AND CHANGE OF DISPLAY

■ With each pressing of Button A, the display changes in the following order. TIMER TIME/CALENDAR STOPWATCH ALARM → RFCALL display display

f the timer mark "O" is flashing in the disp

snlav other than the stopwatch display

set, the watch emits a brief sound when the

anged to the TIME/CALENDAR display, th

Button (SAT Button (Button (E) • The built-in illuminating light function can be operated by tapping the watch face:

(2) How to set the time and calendar

The city name currently set starts flashing.

②Press Button E to select the item to be adjusted (flashing).

(1) Buttons and operations

HOW TO SET THE TIME AND CALENDAR

Long press Button (A) to show the TIME/CALENDAR SETTING display.

*If the "DST (summer time)" is set to "on," the "DST" mark is displayed and the

Press Button A to show the TIME/CALENDAR display.

Button (A): Change to TIME/CALENDAR display Button (Iong press): Change to TIME/ CALENDAR SETTING display Button B: Selection of city name, adjusting items or digits (moving back or decreasing) hourly time signal, adjusting items or digits (advancing or increasing) Button ©: WORLD TIME display/selection of the item or digit to be adjusted

Tapping × two times: Setting/canceling the

auto illumination

then press Button B or C in accordance with a time signal. 4) After selecting the item to be adjusted, press Button © or 0 to set the digits. With each pressing of Button ©, one digit is increased or the city name advances one by one. (With each pressing of Button ®, one digit is decreased or the city name moves back one by one). (Except "second," "12H/24H," and "DST")

With each pressing of Button ©, the display changes in the following order.

⑤After all adjustments are completed, press Button A to return to the TIME/CALENDAR display. If the watch is left untouched with the digits flashing, the display will automatically return to the TIME/CALENDAR display in two to three minutes.

e year, month, date, and day from 2014 to 2063 have been programmed in the automatic n this period, it is not necessary to manually adjust odd and even months including

February of leap years.
If summer time is set in the TIME/CALENDAR display and the same city is selected in the WORLD TIME display, the summer time will also be shown in the WORLD TIME display.
If all indicators of the display light while in the TIME/CALENDAR SETTING display, it is not a malfunction. This happens if buttons C and D are pressed at the same time. In such a case, press any one of buttons to return to the TIME/CALENDAR display, and then, follow the above procedures the process of the contributions and elevations.

②Long press Button © to show the POWER SAVE SETTING display.

The contrast level of the display (variations of shading) can be adjusted. When the digital display is initialized or the built-in IC is reset the contrast is reset to the default level "O" Press Button (A) to show the TIME/CALENDAR display

(3) How to adjust the contrast level

 \bigcirc Long press Button \bigcirc to show the TIME/CALENDAR SETTING display. 3To reset the seconds to "00," press Button (E) to select the second digits (flashing), and

The city name currently set starts flashing. ②Press Button E to select "contrast."

③Press Button B or C to adjust the contrast $(Low)-2 \longleftrightarrow -1 \longleftrightarrow 0 \longleftrightarrow 1 \longleftrightarrow 2 (High)$

Contrast level: 0 (4) After the adjustment is completed, press

Adjust the tap sensitivity. ● Press Button (A) to show the TIME/CALENDAR display

Button (A) to return to the TIME/CALENDAR display. If the watch is left untouched with the digits flashing, the display will automatically return to the TIME/CALENDAR display in two to three minutes.

(4) How to adjust the POWER SAVE setting Press Button (A) to show the TIME/CALENDAR display ①Long press Button A to show the TIME/CALENDAR SETTING display. The city name currently set starts flashing.

Long press Button (A) to show the TIME/CALENDAR SETTING display. The city name currently set starts flashing. Press Button © to show the TAP SENSITIVITY SETTING display. Sensitivity Low Sensitivity High ③Press Button B or Button C to adjust the tap sensitivity.

(5) How to adjust the tap sensitivity

(6) How to test the alarm sound and how to engage/disengage the hourly time signal and confirmation sound for button operations
-With each pressing of Button © in the TIME/CALENDAR (Hourly time signal does not sound.) display, the hourly time signal and confirmation sound for button operations can be engaged or disengaged. The alarm sound can be heard by pressing and

If the watch is left untouched with the digits flashing, the display will automatically return to

holding Button © and D at the same time.

③Press Button ® or Button © to select the OFF or set

OFF \longleftrightarrow 1H \longleftrightarrow 3H \longleftrightarrow 6H \longleftrightarrow 12h

(4) After the adjustment is completed, press Button (A) to

the TIME/CALENDAR display in two to three minutes.

time. The factory default setting is OFF.

return to the TIME/CALENDAR display.

When POWER SAVE is OFF

FEATURES

This is a runner's watch that can store up to 300 units of measured memory and can recall data on demand. Data within 300 units of memory can be sorted by channel when being stored. The results measured by the stopwatch function can be recalled, and when results are recalled, the best lap time and average lap time can be also displayed. This watch is equipped with a target timer function. The target timer is a

countdown timer that works in conjunction with the stopwatch operation, and is displayed together with the stopwatch.

Also, the watch employs a tapping method for switching the light; a

(1) Buttons and operations slight tap on the watch face turns on the light. In addition, this watch is equipped with a 3-channel alarm function, timer function, and world time function which can display the time of 44

cities (including GMT) throughout the world. TIME/CALENDAR Month, date, day, hour, minute, second, and summer time mark can be displayed

Either of a 12-hour indication or a 24-hour indication of time display can be selected. (The western calendar year is displayed only when adjustments are made.) The calendar automatically adjusts for odd and even months including February of leap years from January 1, 2014 to December 31, 2063 (Automatic calendar). STOPWATCH The stopwatch can measure up to 99 hours 59 minutes 59 seconds 99

in 1/100 second increments.
Up to 300 units of lap time and split time memory can be stored

Up to 300 units of memory can be sorted by channel when being stored. The display positions can be changed over between lap time and split time. Equipped with a target timer function that works in conjunction with the stopwatch operation The current time is constantly displayed even when the stopwatch is working. MEMORY RECALL The stored data (lap number, lap time, and split time) can be recalled

on demand after the measurement.

•The total time, best lap, and average lap can be displayed.

The watch is equipped with a double repeat timer function which allows you to set two different timer times. The timer can be set from 10 seconds up to 99 hours, 59 minutes in one-second increments The number of times that the timers repeat their cycles can be set from 1 to 100 times. The number of times the countdown has been completed is displayed.

•The three-channel daily alarm sounds at a designated time (hour and minute) every 24 hours. ·Each alarm channel can be engaged ("on") or disengaged ("--") independently. WORLD TIME

The time of 44 cities (including GMT) in different time zones throughout the world can be displayed. The summer time (DST) can also be set for each city (except GMT). THE BUILT-IN ILLUMINATING LIGHT (LED) FUNCTION/TAP INPUT FUNCTION Tapping the watch face once illuminates the display for approximately 4 seconds. Tapping the watch face two times sets/cancels the auto illumination function.

[Function to change the display to the TIME/CALENDAR display] A special button is provided to change any display to the TIME/CALENDAR display.

■ HOW TO USE THE STOPWATCH

Lap time "LP" and split time "SP" can be displayed simultaneously. The memory of best lap time and average lap time can be stored. •Up to 300 units of memory can be sorted.

Button

•Data within 300 units of memory can be sorted by channel when being stored. ·Lap/split time, best lap time, and average lap time can be recalled on the display

Press Button (A) to show the STOPWATCH display.

Start → Stop/Restart → Lap/Split → Stop → Reset

Start → Lap/Split → Lap/Split → Stop → Reset

Button B 500000 Button © Button (A): Change to the STOPWATCH display Button B: Changes over the display positions between lap time and split time Button ©: Start/Stop Button D: Change to the TIME/CALENDAR display Button E: Lap. Split/Reset Button D Tapping imes one time: Turning on the built-in light Button (Tapping \times two times: Setting/canceling the auto illumination

"Lap time" is the time that has elapsed from the start of one stage of an activity to that of the next stage. "Split time" is the time that has elapsed from the start of an Split time activity to any given stage.

Units of memory used for storing 1 time data How to measure time Start → Stop → Reset 3 to 4 units of memory Start → Stop/Restart → Stop → Reset 3 to 4 units of memory 3 Start → Lap/Split → Stop → Reset 4 to 5 units of memory

sed, but if data is divided and stored in 2 channels, 297 units of memory can be used in total. When the lap/split time is measured, if the "FULL" and the lap number alternately flash, the p/split time cannot be stored. This indicates that the memory is full.

"F---" is displayed on the bottom row when the stopwatch function is used, the memory of split time cannot be stored. (See "How to use the memory recall function" and delete

•The stopwatch can measure up to 99 hours 59 minutes 59 seconds 99 in 1/100 (2) How to display the measured time

●Each time Button [®] is pressed, the display positions are changed over between "LP" time and "SP" time

Button L-10 12:31

The bottom row constantly displays the current time.

·After starting the stopwatch, "F-300" changes to "L-1."

When the time exceeds one hour, the LP/ SP display section on the left side shows hours Button (Start Lap/Split Lap/Split Lap/Split

(3) How to use the stopwatch (Standard measurement) Button (Button (Button (Button (Button Start Stop Stop Reset Restart If "F-300" is displayed, it means that 300 units of memory can be used. "F-297" means that 297 units

(4) Lap time/split time measurement (if lap time measurement is repeated 10 times) Button (Button (Start Lap/Split Lap/Split Stop Reset •After starting the stopwatch, "F-300" changes to "L-1." of memory can be used.

(5) How to use the TARGET TIMER

•The target timer starts, stops, resets, and restarts counting in conjunction with operation of the START, STOP, and LAP/SPLIT buttons of the stopwatch. When the TARGET TIMER is ON, the "TT" mark lights up on the left side of the display. The timer

set time is displayed on the top row, and the timer operates in conjunction with the stopwatch. When the timer set time is reached, the timer sounds (with a 3-second countdown function). uring the LAP time, the display on the top row shows the difference between the set time and

*If there is no operation after the elapse of the TARGET TIMER set time, the bar display "----" flashes

How to check and set the TARGET TIMER time ·Long press Button (A) in the state where the stopwatch is reset to show the TARGET TIMER SETTING display.

·Items and digits to be adjusted are selected by Button E, and digits are decreased and increased by Button (B) and Button (C), respectively •The time can be set between one to fifty-nine minutes fifty-nine seconds in one-second increments.

When the setting is finished, press Button (A) to return to the STOPWATCH RESET display.



adjustment setting adjustment





Stop

↓ ↑ Button



Button (C Button (Reset The date when the measurement is

*The LAP time and SPLIT time positions are displayed in accordance with the stopwatch disp

4To check data in other channels, press Button B or C to

(1) Buttons and operations

Button (A): Change to MEMORY RECALL display Button (A) (long press): Data deletion

Button (Selection of channe : Change to the TIME/CALENDAR display Button (E): Data recall Tapping × one time: Turning on the built-in light

illumination *If no data is stored in memory, "---" mark is displayed

Example: If you want to see data in channel 5 (CH-5) 1)Press Button (B) and (C) to show the desired

Button

Best lap time CH display Total measurement time Lap time (No Indication) Split time Split time Total measurement Lap time Lap time Average

select the desired channel number and check the data in the same way as procedure (3) (3) How to delete the stored data

Press Button (A) to show the MEMORY RECALL display.

Press Button B or C to select the channel you want to delete.

Press Button A for approximately 2 seconds. "CLR?" will be displayed.

2 seconds. When "ALL CLR?" is displayed, release Button A (5)After the number of remaining units is

displayed, the watch automatically returns to the MEMORY RECALL display.

How to delete all channels

①Press Button A to show the MEMORY RECALL display.

Press Button A for approximately 2 seconds. "CLR?" will be displayed.

③Keep Button (A) pressed for approximately 2 seconds to show "ALL CLR?" And then keep Button (A) pressed for

approximately another 2 seconds. 4) After the number of remaining units is displayed, the watch

automatically returns to the MEMORY RECALL display.

HOW TO USE THE TIMER

The timer can be set from 10 seconds up to 99 hours, 59 minutes in one-second increments. •Two timers are provided, and the timer 2 starts after the timer 1 counted up. The repeating •Each alarm channel can be engaged ("on") or disengaged ("--") independently. function is also included so that the timer 1 restarts after the timer 2 counted up. To use either Timer 1 or Timer 2 as a standard repeat timer, set the timer not in use to "00:00'00." The number of times the timers repeat the countdown can be set from 1 to 100 times.

Button (A): Change to TIMER display Button (A) (long press): Change to TIMER

Tapping × one time: Turning on the built-in light Tapping × two times: Setting/canceling the Button 🗓 Button auto illumination

Example: If the timer 1 is set to three minutes, the timer 2 is set to one minute, and the repeating number is set to 5.

①Press Button (A) to show the TIMER display ②Long press Button A to show the TIMER SETTING display. The hour digits for Timer 1 starts flashing. Press Button E to select the item or digits to be adjusted (flashing).

TO BE REPEATED ③With each pressing of Button O, one digit is increased. (With each pressing of

④Press Button ⑥ to return to the TIMER display. If the watch is left untouched with the digits flashing, the display will automatically return to the TIMER display in two to three minutes.

(TIMER 1:3 minutes) (TIMER 2:1 minute) (THE NUMBER OF TIMES THE COUNTDOWN IS (TIMER display) TO BE REPEATED: 5 times) ⑤Press Button ⑥ to start/stop the timer. After stopping the timer,

press Button (E) to reset the timer arting and stopping the timer can be repe **A time-up warning beep sounds 3 seconds before the set time is up. When the set time is up, the time-up beep sounds for approximately 5 seconds.

**To stop the time-up warning beep and time-up beep while sounding, press either Button (A), (B), (C), (D), or (E). *While the timer is counting, the timer mark "O" flashes.

HOW TO USE THE ALARM

(1) Buttons and operations Press Button (A) to show Button (A): Change to ALARM display the ALARM display. Button (Iong press): Change to ALARM
TIME SETTING display : Alarm time setting (decreasing digits) Button ©: Alarm time setting (increasing digits)

4 to 5 units of memory

5 to 6 units of memory

Engagement/disengagement of the alarm Change to the TIME/CALENDAR display · Change between the alarm 1 2 and 3 Button (E Button (A Button Tapping × one time: Turning on the built-in light Tapping × two times: Setting/canceling the Button (E auto illumination (2) How to use the alarm The way of using the alarm is the same for every alarm

time to "6:30 a.m." ①Press Button ⑤ to show "ALARM 1."
Long press Button ⑥ to show the ALARM SETTING display. The hour digits start flashing. 2) With each press of Button (E), hour digits and minute digits flash alternately. Select the digits to

Example: Selecting alarm 1 and setting the alarm

be adjusted (flashing).

③With each pressing of Button ©, one digit is increased. (With each pressing of Button ®, one digit is decreased.) 4) After all adjustments are completed, press Button (A) to

release the ALARM SETTING display and to return to the ALARM 1 display. If the watch is left untouched with the digits flashing, the display will automatically return to the ALARM 1 display in two to three minutes.

·With each pressing of Button © in the ALARM display, "ON" (the alarm is engaged) or "--" (the alarm is disengaged) mark is displayed alternately.

any of Buttons (A), (B), (C), (D), (E), (F) or (G).

(3) How to engage or disengage the alarm (4) How to stop the alarm while sounding ·At a designated time the alarm sounds for (Alarm disengaged) approximately 20 seconds and automatically stops. To stop the alarm manually while sounding, press

HOW TO USE THE WORLD TIME

•The three-channel daily alarm sounds at a designated time (hour and minute) every 24 hours. •The time of 44 cities (including GMT) in different time zones (4) Comparison table between city and time difference (GMT indicates the Greenwich mean throughout the world can be displayed. •The summer time (DST) can also be set for each city (except GMT).

> (1) Buttons and operations Button (B) \ Button (Button (A Button (Button (

(2) How to use the world time

Button (A): Change to WORLD TIME display Button B: Selection of the city (moving back) Button (Selection of the city (advancing) : Change to the TIME/ Button (CALENDAR display Button (E): Setting/canceling the DST Tapping × one time: Turning on the built-in light Tapping × two times: Setting/canceling the

②To select the city, press Button © or D. (3) How to set the summer time •With each pressing of the Button (a) in the WORLD TIME display, the summer time can be alternately set or cancelled. ·When the summer time is set, the DST mark appears.

(When the summer

■ NOTE ON THE LIQUID CRYSTAL PANEL

1) Press Button (A) to show the WORLD TIME display

The city name, month, date, and time are displayed.

The normal life expectancy for the liquid crystal panel of the watch is approximately 7 years. After that, it may decrease in contrast, becoming difficult to read. Please contact the retailer from whom the watch was purchased to have the liquid crystal panel replaced with a new one.

time. + indicates advancement from the GMT and - indicates time lag from the GMT.

(As of November 2014)

Immediately stop wearing the watch in following cases. Olf the watch body or band becomes edged by corrosion etc. Olf the pins protrude from the band

Keep the watch and accessories out of the reach of babies and children Care should be taken to prevent a baby or a child accidentally swallowing the accessories. If a baby or a child swallows the battery or accessories, immediately consult a doctor, as it will be harmful to the health of the baby or child. •Do not remove the battery from the watch.

Please ask a watch retailer for replacement of the battery. Do not recharge the battery, as doing so can generate heat which may cause bursting, leakage or ignition. Do not use the watch in scuba diving or saturation diving. The various tightened inspections under simulated harsh environment, which are usually required for watches designed for scuba diving or saturation

diving, have not been conducted on the water-resistant watch with the BAR (barometric pressure) display. For diving, use special watches for diving.

·Avoid wearing or storing the watch in the following places. Places where volatile agents (cosmetics such as polish remover, bug repellent, thinners etc.) are vaporizing Places where the temperature drops below 5 °C or rises above 35 °C for a long time Places of high humidity Places affected by strong magnetismor static electricity

Do not pour running water directly from faucet.

Do not disassemble or tamper with the watch.

TO PRESERVE THE QUALITY OF YOUR WATCH

Replacement of the battery requires professional knowledge and skill

Places affected by strong vibrations If you observe any allergic symptoms or skin irritation Stop wearing the watch immediately and consult a specialist such as a dermatologist or an allergist.

The water pressure of tap water from a faucet is high enough to degrade the water resistant performance of a water resistant watch for everyday life. •Do not turn or pull out the crown when the watch is wet. Water may get inside of the watch.

ed or SEIKO CUSTMER SERVICE CENTER. •Do not leave moisture, sweat and dirt on the watch for a long time. Be aware of a risk that a water resistant watch may lessen its water resistant performance because of deterioration of the adhesive on the glass or gasket, or the development of rust on stainless steel.

Do not wear the watch while taking a bath or a sauna. Steam, soap or some components of a hot spring may accelerate the deterioration of water resistant performance of the watch. Replacement of the metal band requires professional knowledge and skill. Please ask a watch retailer for replacement of the metal band, as there is a risk of hand or finger injury and fear of losing parts.

Keep the watch out of the reach of babies and children. Extra care should be taken to avoid risks of any injury or allergic rash or itching that may be caused when they touch the watch. When disposing of used batteries, follow the instructions of your local authorities.

SPECIFICATIONS ■ AFTER-SALE SERVICE Notes on guarantee and repair

> certificate of guarantee to receive repair services. For the display function: ·Guarantee coverage is provided in the Between 0°C and +50°C certificate of guarantee. ·· Nematic Liquid Crystal, Read carefully and retain it.

For repair services after the guarantee period has expired, if the functions of the watch can be restored by repair work, we will undertake repair services upon request and payment.

·Within the guarantee period, present the

The watch requires good daily care Wipe away moisture, sweat or dirt with a soft cloth

Water resistance

Non-water resistance Avoid drops of water or sweat The watch withstands accidental contact WARNING Nater resistance for veryday life Water resistance for everyday The watch is suitable for sports such as swimming. fe at 5 barometric pressures Vater resistance for everyday life The watch is suitable for diving not using an air cylinder

·Moisture. sweat

ODusty places

·Lack of care may cause a yellowish or gold stain on the lower sleeve edge of shirts. ·Wipe off moisture, sweat or soil with a soft cloth as soon as possible ·To clean the soil around the joint gaps of the band, wipe it out in water and then brush it off with a soft toothbrush.

Because some titan bracelets use pins made of stainless steel, which has outstanding strength, rust may form in the stainless steel parts. ·If rust advances, pins may poke out or drop out, and the watch case may fall off the bracelet, or the clasp

may not open. If a pin is poking out, personal injury may result. In such a case, refrain from using the watch and request

·Wipe off moisture and sweat as soon as possible by gently blotting them up with a dry cloth. •Do not expose the watch to direct sunlight for a long time. Please take care when wearing a watch with light-colored band, as dirt is likely to show up.

Refrain from wearing a leather band watch other than Aqua Free bands while bathing, swimming, and when working with water even if the watch itself is water-resistant enforced for daily use (10-BAR water resistant)

A polyurethane band is susceptible to discoloration from light, and may be deteriorated by solvent or atmospheric humidity. Especially a translucent, white, or pale colored band easily adsorbs other colors, resulting in color smears or discoloration Wash out dirt in water and clean it off with a dry cloth.

(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.) ·When the band becomes less flexible, have the band replaced with a new one. If you continue to use the band as it is, the band may develop cracks or become brittle over time.

Skin irritation caused by a band has various reasons such as allergy to metals or leathers, or skin reactions against friction on dust or the band itself. •Contact the retailer the watch was purchased from or SEIKO CUSTOMER Notes on the length of the band

●Inspection and adjustment by disassembly and cleaning (overhaul) ·Periodic inspection and adjustment by disassembly and cleaning (overhaul) are recommended approximately

According to use conditions, the digital display may go out due to liquid leakage. As the parts such as the gasket may deteriorate, water-resistant performance may be impaired due to intrusion of perspiration and moisture.

Please contact the retailer from whom the watch was purchased for inspection and adjustment by disassembly and cleaning (overhaul). For replacement of parts, please specify "SEIKÓ GENUINÉ PARTS." When asking for inspection and adjustment by disassembly and cleaning (overhaul), make sure

your watch may be replaced.

malfunction may be caused due to battery leakage, etc. Have it replaced with a new one as soon as possible. 3 Battery replacement is charged even if it runs down within the guarantee period.

purchased, and specify a genuine SEIKO battery.

This watch operates for two years after assembling a new normal battery. (2) Monitor battery

1.Notes on the battery

(1) Battery life

REMARKS ON THE BATTERY

The battery in your watch may run down in less than two years after the date of purchase, as it is a monitor battery which is inserted at the factory to check the function and performance of the watch. (3) Battery replacement ①For battery replacement, be sure to have the battery replaced with a new one at the retailer from whom the watch was 2.Battery life indicator

2If the old battery is left in the watch for a long time, a

of your watch.

Please note that it takes several days to check the water checking, therefore, please check the period required for it.

have the battery replaced with a new one, also request the

water resistance test pertaining to the water resistant quality

The watch is equipped with a battery life indicator that enables

In such a case, immediately have the battery replaced with a new

you to know when the battery needs to be replaced.

one by the retailer from whom the watch was purchased

①Once the case back is opened for battery replacement or ·After the battery is replaced with a new one, or when an abnormal other purposes, the original water resistant quality designed display such as broken digits appears, follow the procedure below. for the watch may deteriorate when it is closed. When you The built-in IC will be reset and the watch will resume normal How to reset the built-in IC f your watch has 10-bar or higher water resistant quality, be Keep buttons (A), (B), (C) and (D) pressed at the same time for 2 to 3

NECESSARY PROCEDURE AFTER THE BATTERY CHANGE (RESETTING THE IC) TROUBLESHOOTING

sure to have such test performed on the watch every time the seconds. The display will become blank, and "1-1 WED AM 12:0000" will be displayed as the buttons are released. resistant quality of your watch. When requesting the Before using the watch, set the watch in the following order. 1)Time/calendar setting Button (B)

Button (A

Button © WED Button ① Button (E

Solution Possible cause The watch stops operating. ·The battery has run down ·Have the battery replaced with a new one immediately by the eailer from whom the watch was purchased.

•The watch has been left in extremely high or low temperatures for a long time the watch temperature returns to The watch temporarily gains/loses time. normal. Set the correct time before use. You dropped the watch, hit it against a hard Set the correct time before use. If the surface or wore it while playing active sports.

The watch was exposed to strong vibrations. purchased. ·Have the battery replaced with a new one as soon as possible by the retailer from whom the watch was purchased. All the segments of the The battery nears its end. display are flashing. The blur in the glass ·Water got inside the watch due to the | ·Consult the retailer from whom the persists for a long time. deterioration of the gasket, etc. *For the solution for troubles other than above, contact the retailer from whom the watch was purchased

range between 5°C and 35°C) (3) Operational temperature range······ Between −10°C and +60°C

FEM (Field Effect Mode) Miniature lithium battery SB-T1. 1 piece Approx. 3 years (7) Battery life indicator (8) IC (Integrated Circuit) Oscillator, frequency divider

SERVICE CENTER for repair.

■ HOW TO USE THE MEMORY RECALL FUNCTION

Press Button (A) to show the MEMORY RECALL display.



(2) How to use the memory recall function

channel number (CH-5).

②Press Button ⑤ to check the lap time. With . . . (EH = - : each pressing of Button E, the display RECALL



·Up to 300 units of memory can be used to store measured time data. The stored data can be recalled per channel.

 The best lap time and average lap time can be displayed ·The date when the measurement is started is memorized in each channe

Button (B) / 13 12-31



(No Indication)



SETTING display 3: Timer time setting (decreasing digits Button (E : Timer time setting (accreasing digits)
: Timer time setting (increasing digits)
: Change to the TIME/CALENDAR display Button (: Selection of the item or digits to be adjusted Reset the timer

(Minute: 30 minutes) ↓ (A) (Alarm engaged)

(Hour: 6 a.m.

↓ €

Alarm mark disappears.

time is set) ※If summer time is set to the city which has also been set as "HOME" in the TI TIME display, the summer time will also be shown in the WORLD TIME display

■ BUILT-IN ILLUMINATING LIGHT (LED) The watch employs a method to uniformly diffuse light from a light-emitting diode (LED) by light guiding panel.

hen the voltage gets lowered with the battery life running out, the luminance

(1) Frequency of crystal oscillator 32,768Hz (2) Loss/gain (monthly rate) Less than 20 seconds (when the watchis worn on your wrist in the temperature

(6) Battery life

and driving circuits (C-MOS-LSI), 1 piece *The specifications are subject to change without prior notice, for product

After soaking the watch in seawater, be sure to wash the watch in clean pure water and wipe it dry carefully. ratch is rated as "non-water resistant" or "water resistant for daily use," do not wash the watch

Refer the table below for the description of each degree of water resistant performance of your watch

The band touches the skin directly and becomes dirty with sweat or dust. Therefore, lack of care may accelerate deterioration of the band or cause skin irritation or stain on the sleeve edge. The watch requires a lot of attention for long usage. Metallic band will cause rust even on a stainless steel band if they are left for a long time

(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.)

Leather band ·A leather band is susceptible to discoloration and deterioration from moisture, sweat and direct sunlight.

Polyurethane band

Notes on skin irritation and allergy

Adjust the band to allow a little clearance with your wrist to ensure proper airflow When wearing the watch, leave enough room to insert a finger between the band and your

once every 3 to 4 years in order to maintain optimal performance of the watch for a long time.

that the gasket and push pin are also replaced with new ones.

·When your watch is inspected and adjusted by disassembly and cleaning (overhauled), the movement of

